



ASSEMBLY INSTRUCTION

Pump raft system 80-180-460-600

applicable for Master, Matador, Maxi & Magnum









www.grindex.com







Safety





Sicherheit / Veiligheid / Sécurité / Sicurezza / Seguridad /Segurança /Säkerhet /
Sikkerhed / Turvallisuus / Ohutus / Drošība / Sauga / Bezpiecēšņotība / Bezpečnost
/ Varnost / Bezpečnosť / Biztonság /Ασφαλεια / Безопасности




Assembly instruction Pump raft system 80-180-460-600




Assembly instruction Pump raft system 80-180-460-600



Assembly instruction Pump raft system 80-180-460-600



Pump Raft System	appl. for pump	Lifting capacity (kg)	A (mm)	B (mm)	C (mm)	D (mm)	Ø E (mm)
80	Master	80	1200	1200	800	700-900	800
180	Matador	180	1200	1200	800	800-1000	800



Pump Raft System	appl. for pump	Lifting capacity (kg)	A (mm)	B (mm)	C (mm)	D (mm)	Ø E (mm)
460	Maxi	460	3600	1200	800	1000-1200	800
600	Magnum	600	3600	1200	800	1300-1500	800

